





The finished product

Four of six garden beds built in Acton Park, Tasmania.

Tools

Tape measure, pencil and square.
Circular saw (depth of cut >75mm), hand saw or chain saw.
Spirit level
Impact driver.

Materials

15 x 2.4m treated pine sleepers.
Bugle screws.
Black garden plastic.

Need help?

We can adapt our designs to suit your space or build to your design. Contact Us at ClearItProperty.com or by calling 0448716963

